

LIMITED WARRANTY

If you purchased this product new in the U.S. or Puerto Rico, **CORTELCO** warrants it against defects in material and workmanship for a period of one (1) year from the date of original purchase. This warranty is in lieu of all other express warranties. During the warranty period, **CORTELCO** agrees to repair or, at its option, replace the defective product, or any part of it without charge for parts or labor. This is your exclusive remedy. This warranty does not cover damage resulting from accident, misuse, abuse, improper installation or operation, lack of reasonable care, the affixing of any attachment not provided by **CORTELCO** with the product and loss of parts. The warranty is voided in the event any unauthorized person alters or repairs the unit. Telephone companies use different types of equipment and offer various types of services to customers. **CORTELCO does not warrant that this product is compatible with the type of equipment of any particular phone company or the services provided by it.**

CORTELCO DISCLAIMS ANY IMPLIED WARRANTY, INCLUDING THE WARRANTY OF MERCHANTABILITY AND THE WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE, AS OF THE DATE ONE YEAR FROM THE ORIGINAL PURCHASE OF THE PRODUCT. **CORTELCO** ASSUMES NO RESPONSIBILITY FOR ANY SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES.

THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, AND YOU MAY HAVE OTHER RIGHTS WHICH VARY FROM STATE TO STATE. SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES OR LIMITATIONS ON

HOW LONG AN IMPLIED WARRANTY LASTS, SO THE ABOVE EXCLUSION AND LIMITATION MAY NOT APPLY TO YOU.

If failure occurs and your telephone is in warranty, service shall be provided by returning it to **CORTELCO - Repair Center, 1703 Sawyer Road, Corinth, Mississippi 38834, shipping prepaid**. The product will be repaired or replaced if examination by us determines the product to be defective. Telephones received damaged as a result of shipping will require you to file a claim with the carrier.

FOR SUPPORT WITH THIS TELEPHONE, CALL 662-287-5281 AND REQUEST EXTENSION 127, OR E-MAIL tech.support@cortelco.com

Quick Start Guide for 2740 4 Line Telephone System



The 2740 is a 4 Line 16 Station KSU-LESS System. It supports additional station modules for External Paging, Music On Hold, and Door Phone w/Door Striker Control.


The 2740 comes factory-set for "COMMON-LINE" installation which is also called "Square" in telephone terminology. This means all lines are common on all instruments. The 2740 can also support private lines.

[FOR CORRECT FUNCTION, LINE 1 MUST BE LINE 1 ON ALL STATIONS AND IT MUST NOT HAVE LINE FILTERS INSTALLED. THIS MEANS THAT LINE 1 CANNOT BE A DSL OR VOIP LINE]. The 2740 telephone also supports Type II caller ID (Caller ID on Call Waiting).

First, unpack the telephones and check the content of the boxes. Each box should contain:

- 1 Telephone Base
- 1 Telephone Handset
- 1 Telephone Desk Stand
- 1 Power Supply
- 1 Handset Cord (Coiled Cord)
- 2 Line Cords
- 1 7" Line Cord for wall mounting.

1. Connect handset cord to front left of telephone base and to handset.
2. Plug line cord(s) into line connectors on bottom of telephone. Observe the marking for Lines 1&2 and Lines 3&4.



3. Plug power transformer into a non-switched electric outlet, then plug the connector into the base.
4. After connecting power to the telephone a station number must be assigned. The first station number is 01. The last station number is 16.

To reset the telephone to default settings, press MENU, then press MUTE twice, then press 2741. This will cause all programming to be lost including any Caller ID information or Memory Speed Dials. The line buttons will start to flash and the display will show all of the assigned stations along the top of the display. The display will show "Station #??" with a soft key labeled "Change". Press the "Change" soft key and the first available station number will appear flashing. Press "Menu" key to save station number or press "Change" to go to next available station number.

The following menu tree is for your assistance in programming the telephone system. To start the programming, press the MENU button and use the Up and Down Arrows to move in the menu with the Soft Key to make selections. Please see User Guide for detailed instructions. You may download a copy of the User Guide at www.cortelco.com.

Menu Tree for Model 2740

First level

- Phone Setting
- Memory Setting
- Time/Date Set
- Advanced Setting

PHONE SETTING

- Station #
 - 01 - 16
- Do Not Disturb:N
 - N (for NO) / Y (for YES)
- Ringer Settings
 - L1, L2, L3, L4 Ringer:
 - ON/DELAY/OFF
- Off Hook Ring:Y
 - Y (for YES) / N (for NO)
- Intercom Prefs
 - Intcm:
 - RING/VOICE/
 - HANDSFREE
 - Pages:
 - ALLOWED/BLOCKED

Line Type

- L2, L3, L4:
 - COMMON/ PRIVATE /
 - UNCONNECTED

Auto Seize:

- L1/L2/L3/L4/INTCM

Distinctive Ring

- RING SOUND#
 - L1, L2, L3, L4:
 - <1,2,3,4,5,6,7,8>

Area Codes

- Home Code:XXX
- Local Code1 - 6:xxx
- 1Plus7 Code1 - 6:xxx

Telco VMWI

- VMWI: Line
 - <L1, L2, L3, L4, OFF>
- VMWI: (type)
 - <FSK/STUTTER>

Caller ID Store

- L1 - L4 CID Store
 - <ON/OFF>

Toll Restriction

- Enter Code:1234
- Set Restricted #
 - 1 - 5:
- Set Allowed #
 - 1 - 5:

Line Restriction

- L1 - L4:
 - NORMAL/RESTRICTED

Station Naming

- For 16 stations
 - (set at station #01)

Hold Remind

- <OFF/30s/1 min/2min>
- Centrex Prefix
 - Prefix:XXXXXXX
 - Prefix:
- Message Lamp
 - RESET
- CIDCW:
 - <HIGH SENS/OFF/LOW SENS>

End of List

MEMORY SETTING

- Select Location
- Empty Location or the number previously stored is shown
- After M1, M2, M3, M4 or M5 is pressed
 - Directory
 - After # is pressed

TIME/DATE SETTING

- TIME:
 - (13:44)/(HH:MM)
- AM/PM:
 - AM/PM
- DATE:
 - (01/01/00)/(MM/DD/YY)

ADVANCED MEMORY SETTING

- Erase Memory
 - Memory Dials
 - Erase Settings
 - Erase Toll Restr
 - Enter Code:
 - Headset Type
 - Hst:
 - 2.5mm/HANDSET
 - Flash Time:
 - 600ms/1s/100ms/300ms
 - Hold Drop:
 - 30MIN / 99MIN / 5MIN / 15MIN
 - Hold Release:
 - ON/OFF
 - Station #:
 - NORMAL/LOCKED
 - Loop Detect:
 - 48V/24V/12V/OFF
 - Tone/Pulse:TONE
 - TONE/PULSE
 - System Privacy:Y
 - Y (for YES) / N (for NO)
- This option only appears for station #01