

## Private Hold

The key can be configured as a private hold key. During a conversation, all members belonging to that particular SLA group can use this key to hold the call, but only the initiator can retrieve the call. For the configuration, please refer to the setting of Conference.

## Shared Line

Share Line Appearance (SLA) allows subscribers to share SIP lines and also provides status monitoring of the shared line. When a user places an outgoing call using such an appearance, all members belonging to that particular group are notified of this usage and are blocked from using this line appearance until the line goes back to idle state or when the call is placed on hold. Similarly all members of the SLA group are notified of an incoming call and the call can be picked up on a line appearance associated with the extension. For the configuration, please refer to the setting of Pick Up.

## XML PhoneBook

If you set the XML PhoneBook function, the phone will automatically download the corresponding phone book from the server, and into the XML PhoneBook page when you press the key.

To assign the key as XML PhoneBook via Web interface:

- 1) Choose Phone->EXT Key, choose one of the key you want to make the assignment, choose XML PhoneBook from the list in the Type field.
- 2) Fill in the name to the label which you want.
- 3) In the "Line" field, select a PhoneBook, and press Confirm button to save the changes.

## Group Pickup

When you configure a Group Pickup, specify the extension that you want to monitor. When the monitored extension receives a call, pressing it to pick up the call. If the monitored extension receives multiple incoming calls simultaneously, the IP Phone UI displays a list of incoming calls. You can select a call and connect. For the configuration, please refer to the setting of Pick Up.

## Paging

You can configure the key as Paging. When you press this key, the phone will dial the number out directly. For the configuration, please refer to the setting of Pick Up.

## Record

Call recording is a phone function to record the conversation in the process of dialog. For the configuration, please refer to the setting of Conference.

## XML Browser

Xml browser is a simple browser function, which is based on xml language and http/https service, users can use tools such as PHP, JavaScript, etc., accordance with the established syntax, to generate server-side functions dynamically to meet the needs of the user xml file, and then downloaded it to sip phone by http/https, so as to realize a simple browser features. Using xml browser, customers can achieve the personalized features, such as weather information, access to address book and other functions. For the configuration, please refer to the setting of Forward.

## Hot Desking

Hot Desking is regularly used in places where not all the employees are in the office at the same time, or not in the office for very long at all, which means actual personal offices would be often vacant, consuming valuable space and resources.

Hot Desking is a phone feature that allows accounts to login or logout in an IP phone. After a certain account logging, the corresponding configuration of the account will be applied to the phone. For the configuration, please refer to the setting of Forward.

## URL Record

You can set this key as URL Record, recording the call when you press the key. For the configuration, please refer to the setting of Forward.

This manual is only for reference, please refer the user manual for more information. We reserve the right to improve or change the product and the user guide without notice.


You can download the latest user manuals from our website:

<http://www.yealink.com/en/download.asp?BigClassName=IP%20Phone>

V51.0

**Yealink**  
EASY VOIP

# Expansion Module EXP39



## Quick Reference

[www.yealink.com](http://www.yealink.com)

V51.0

You can use the web interface or the IP phone user interface to configure key functions. Pressing the special key of the EXP39 you want to set for about 5 seconds, the IP phone will turn to the setting interface of this key. In the following sections, we will make detail description of setting by the web interface.

## Switch

There is only key1 and key21 can set up to switch function. If you set the key1 as Switch, you can enjoy the function of switch. Then the expansion will supply you 38 programmable keys.

To assign the key as Switch via Web interface:

- 1) Choose Phone->EXT Key, choose Swicth from the list in key1, and the key21 only has Switch function.
- 2) Fill in the name to the label which you want, and press Confirm button to save the changes.

## Conference

This key allows a user on a call to conference another party at a pre-defined number.

To assign the key as Conference via Web interface:

- 1) Choose Phone->EXT Key, choose one of the key you want to make the assignment, choose Conference from the list in the Type field.
- 2) Fill in the name to the label which you want, and press Confirm button to save the changes.

## Forward

If the key is configured as Forward key, press this key under the idle status, then when there is any call to the extension number will be forwarded to the set number automatically.

To assign the key as Forward via Web interface:

- 1) Choose Phone->EXT Key, choose one of the key you want to make the assignment, choose Forward from the list in the Type field, enter the number you want to forward in the value field.
- 2) Fill in the name to the label which you want, and press Confirm button to save the changes.

## Transfer

You are able to configure the key as a transfer to perform the Blind/ Semi-Attend /Attended Transfer. For the configuration, please refer to the setting of Conference.

## Hold

The key can be configured as Hold. You can use this key to hold and retrieve a call during the conversation. For the configuration, please refer to the setting of Conference.

## DND

If the key is configured as DND, you are allowed to active the DND function immediately when you press it. Press it again to deactivate DND mode.

For the configuration, please refer to the setting of Conference.

## Redial

If the key is configured as Redial, press the key, it will turn to the Dialed Calls interface.

For the configuration, please refer to the setting of Conference.

## Call Return

When the key is configured as Call Return you are allowed to dial out the last phone call you received.

For the configuration, please refer to the setting of Conference.

## SMS

When the key is configured as SMS you are allowed to access SMS quickly by pressing this key

For the configuration, please refer to the setting of Conference.

## Pick Up

When you configure a Pick Up key, you specify the extension that you want to monitor. Then, when the monitored extension receives a call, you can press this key to pick up the incoming call.

To assign the key as Pick Up via Web interface:

- 1) Choose Phone->EXT Key, choose one of the key you want to pick up, choose Pick Up from the list in the Type field, and enter the number you want to pick up in the value field.
- 2) Fill in the name to the label which you want.
- 3) In the "Line" field, select a line for which to apply this key, and press Confirm button to save the changes.

## Call Park

Call Park is a feature that allows a person to put a call on hold at one telephone set and continue the conversation from any other telephone set. The "call park" feature is activated by pressing a preprogrammed button or a special sequence of buttons. This transfers the current conversation to an unused extension number and immediately puts the conversation on hold. The telephone system will then display the extension number of the parked call so that the call can later be retrieved.

For the configuration, please refer to the setting of Pick Up.

## DTMF

You are allowed to send out the desired DTMF number during the conversation.

For the configuration, please refer to the setting of Forward.

## Voicemail

When the key is configured as Voice Mail you are allowed to access voicemail quickly by pressing this key.

For the configuration, please refer to the setting of Pick Up.

## Speed Dial

You can configure the key as a simplified speed dial. This key function allows you to speed up dialing numbers often used or hard to remember.

For the configuration, please refer to the setting of Pick Up.

## Intercom

You can configure the key for Intercom mode and it is useful in an office environment as a quick access to connect to the operator or the secretary.

For the configuration, please refer to the setting of Pick Up.

## Line

You can set these keys as line keys to active up to the user accounts.

To assign the key as Line via Web interface:

- 1) Choose Phone->EXT Key, choose one of the key you want to make the assignment, choose Line from the list in the Type field, and choose the correspondent line.
- 2) Press Confirm button to save the changes.

## BLF

You can configure the key for Busy Lamp Field use which allows you to monitor the status (idle, ringing, or busy) of other SIP accounts. User can dial out on a BLF configured key on the expansion module EXP39.

To assign the key as BLF via Web interface:

- 1) Choose Phone->EXT Key, choose one of the key you want to make the assignment, choose BLF from the list in the Type field, and enter the number you want to monitor in the value field.
- 2) Then you can fill in the name to the label which you want.
- 3) In the "Line" field, select a line for which to apply this key.
- 4) Enter the feature codes in the extension field, and press Confirm button to save the changes.

## URL

If the key is configured as URL, then pressing this key, you can send HTTP requests to a web server.

For the configuration, please refer to the setting of Forward.

## Group Listening

When the key is configured as Group Listening, you are allowed to enable the Speaker and Handset/Headset mode at the same time. You are able to speak and listen using handset/headset; meanwhile the others near by can listen using speaker. Press it again to get back to the previous mode.

For the configuration, please refer to the setting of Conference.

## Public Hold

The key can be configured as a public hold. During a conversation, all members belonging to that particular SLA group can use this key to hold or retrieve a call.

For the configuration, please refer to the setting of Conference.